

- American Receiving Tubes
- Industrial Receiving Tubes
- European Receiving Tubes
- Picture Tubes

A Jon Hang PHOTOFACT PUBLICATION

Original from

Engineering . 565

FIRST EDITION

FIRST PRINTING — JUNE, 1960 SECOND PRINTING — JUNE, 1960

TUBE SUBSTITUTION HANDBOOK

Copyright © 1960 by Howard W. Sams & Co., Inc., Indianapolis 6, Indiana. Printed in the United States of America.

Reproduction or use, without express permission, of editorial or pictorial content, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein.

Library of Congress Catalog Card Number: 60-13842

Charles to the first of the

TABLE OF CONTENTS

INTRODUCTION	5
SECTION 1	
Cross Reference of American Receiving Tubes	7
SECTION 2	
Industrial Substitutes For Receiving Tubes	55
SECTION 3	
European Substitutes For American Types	59
SECTION 4	
American Substitutes For European Types	67
SECTION 5	
Picture Tube Substitutes	79



INTRODUCTION

The first section of this book lists all receiving tubes which have been or are being manufactured in this country. Also included are the latest tube types registered with EIA but not yet in production. The tubes are listed in the left-hand column. The substitutes in the right-hand column are for only those tubes which have similar, or improved, characteristics and can be inserted directly into the socket. No rewiring or mechanical changes are needed, although the associated service controls may have to be readjusted.

In some instances, the available space around the tube should be considered. For example, although electrically identical to a 6L6GB, a 6L6G is more than one inch taller and a half inch larger in diameter. Thus, the substitution may be physically impossible in some compact equipment.

When making substitutes, do not replace tubes in the right-hand column with those in the left-hand column because this may result in a tube with lesser qualifications being used. For example, the 6AX4 is shown as a substitute for the 6W4. However, where a high heater-to-cathode potiontial exists, the 6AX4 will hold up, whereas the 6W4 will not. Therefore, a 6AX4 obviously should not be replaced by a 6W4.

When no substitutes are shown, this indicates that none are recommended. You should then check Section 2 to see if it gives an industrial replacement. Section 2 lists those receiving tubes that can be substituted by industrial tubes. Industrial tubes are more rugged than receiving tubes in that their peak ratings and power-handling characteristics are much higher. Therefore, it may be desirable from time to time to substitute an industrial tube to get more satisfactory results. The receiving tubes are listed in the left-hand column and the industrial substitutes in the right-hand column.

Sections 3 and 4 list American and European equivalents. If you have an American tube and want to know what European type will serve as a substitute, refer to Section 3. Here

you will find the American tubes listed in the left-hand column and the European substitutes in the right-hand column. If you have a European tube, and need to know what American type can be used as a substitute, refer to Section 4. The European tubes are listed in the left-hand column and the American substitutes in the right-hand column. These listings are very useful because a large amount of foreign-made equipment is being sold in this country and all foreign tubes are not stocked in the parts stores. It is much handier to replace a foreign tube with an American tube from your own stock.

The fifth section of this book lists picture tubes and their substitutes. This section lists all picture tubes—from 10-inch to 30-inch. Although there are tubes smaller than 10 inch, they are practically out of date and only one or two have substitutes. For this reason, they have been omitted from the list. Again, you will find no substitutes shown for some tubes because none are recommended. Always pay particular attention to any notes pertaining to a substitute, since some minor changes may be necessary before the substitute will work satisfactorily.

Section 1

CROSS REFERENCE OF AMERICAN RECEIVING TUBES

This section lists all American receiving tubes and their recommended substitutes. To use this listing, first locate the tube number you need a stubstitute for in the left-hand column. Then refer to the right-hand column for the substitute.

The listing of a certain tube type as a substitute does not necessarily mean the reverse is true. So be sure to look only in the left-hand column for the tube to be replaced.

Substitutes marked with an asterisk (*) should be used only when the filament of the original tube is wired in a parallel circuit. Those tubes marked with a section symbol (§) may not work in all circuits.

	To Replace	Use
	OA2	
	OA3	VR175
	OA4G	
	OA5	
	OB2	
	OB3	VR90
_	OC2	
•	OC3	VR105
4	OD3	VR150
₹	OY4	OY4G
0A2-1AH4	OY4G	OY4
∀ O	OZ4	OZ4A, OZ4G (may require shield)
	OZ4A	OZ4, OZ4G (may require shield)
S	OZ4G	OZ4, OZ4A
8	1A3	
-	1A4	1A4P, 1A4T
-	1A4P	1A41, 1A41 1A4, 1A4T
บ 7	1A4T	1A4, 1A4P
E	1A5G	1A5GT, 1T5GT
E	1A5GT	1A5G, 1T5GT
CE		
ш	1A6	1 A 77 C 77
~	1A7G	1A7GT
•	1A7GT	1A7G
	1AB5	
	1AB6	
	1AC5	1V5
	1AC6	
	1AD4	
	1AD5	
	1AE4	
	1AF4	
	1AF5	
	1AG4	
	1AG5	
	1AH4	

* Parallel-filament circuits only.

To Replace	Use
1AH5 1AJ4 1AJ5 1AK4 1AK5	
1AM4 1AN5 1AQ5	1T4SF 1R5SF
1AR5 1AS5	1U5SF
1AX2 1B3	1B3GT, 1G3GT, 1G3GT/1B3GT, 1J3, 1J3GT, 1K3, 1N2
1B3GT	1B3, 1G3GT, 1G3GT/1B3GT, 1J3, 1J3GT, 1K3, 1N2
1B4P 1B4T 1B5 1B5/25S 1B6	1B4T, 32, 951 1B4P, 32, 951 1B5/25S, 25, 25S 1B5, 25, 25S
1B7G 1B7GT 1B8GT 1C3 1C5G	1B7GT 1B7G
1C5GT 1C6 1C7G	1C5GT, 1Q5G, 1Q5GT 1C5G, 1Q5G, 1Q5GT
1C8 1D5G	1E8 1D5GP, 1D5GT
1D5GP 1D5GT 1D7G 1D8GT	1D5G, 1D5GT 1D5G, 1D5GP
1D8G1 1DN5	1U5

^{*} Parallel-filament circuits only.

	To Replace	Use
	1E3	
	1 E 4G	1E4GT
	1E4GT	1E4G
	1 E 5G	1E5GP, 1E5GT
	1E5GP	1E5G, 1E5GT
	1E5GT	1E5G, 1E5GP
	1E7G	1E7GT
	1E7GT	1E7G
	1E8	1C8
•	1F4	
-	1F5G	
1E3_1J3GT	1F6	
Ļ	1F7G	1F7GH, 1F7GV
E3	1F7GH	1F7G, 1F7GV
_	1F7GV	1F7G, 1F7GH
ES	1G3GT	1G3GT/1B3GT, 1B3, 1B3GT, 1J3, 1J3GT, 1K3GT, 1N2
T U B	1G3GT/1B3GT	1B3, 1B3GT, 1G3GT, 1J3, 1J3GT, 1K3, 1N2
<u>5</u>	1G4G	1G4GT
E X	1G4GT	1G4G
<u>></u>	1G5G	1G5GT, 1J5G
ш О	1G5GT	1G5G, 1J5G
ШС	1G6G	1G6GT
~	1G6GT	1G6G
•	1H2	
	1H4G	1H4GT
	1H4GT	1H4G
	1H5G	1H5GT
	1H5GT	1H5G
	1H6G	1H6GT
	1H6GT	1H6G
	1J3	1J3GT, 1B3, 1B3GT, 1G3GT, 1G3GT/ 1B3GT, 1K3, 1N2
	1J3GT	1J3, 1B3, 1B3GT, 1G3GT, 1G3GT/ 1B3GT, 1K3, 1N2
10	* Parallel-filamen	t circuits only. § May not work in all circuits.

To Replace	Use
1J5G	1G5G, 1G5GT
1J6G	1J6GT
1J6GT	1J6G
1K3	1K3GT, 1B3, 1B3GT, 1G3GT, 1G3GT/ 1B3GT, 1J3, 1J3GT, 1N2
1K3GT	1K3, 1B3, 1B3GT, 1G3GT, 1G3GT/ 1B3GT, 1J3, 1J3GT, 1N2
1L4 1L6	
1LA4	1LA4E
1LA4E	1LA4
1LA6	
1LB4	
1LB6	
1LC5	1LN5
1LC6	1LA6
1LD5	
1LE3	1LF3
1LF3	1LE3
1LG5	
1LH4	
1LN5	
1M3	1N3
1N2	
1N3	1M3
1N5G	1N5GT
1N5GT	1N5G
1N6G	1N6GT
1N6GT	1N6G
1P5G	1P5GT
1P5GT	1P5G
1Q5G	1Q5GT, 1C5G, 1C5GT
1Q5GT	1Q5G, 1C5G, 1C5GT
1Q6	

^{*} Parallel-filament circuits only.

[§] May not work in all circuits.

	To Replace	Use	
	1R4		
	1R5		
	1R5SF	1AQ5	
	1S2	1S2A	
	1S2A	1S2	
	1S4		
	1S5		
	1SA6GT		
	1SB6GT		
	1 T 2		
1R4-2AF4A	1 T 4		
ΑF	1T4SF	1AM4	
7	1T5GT	1A5G, 1A5G	T
Ä	1U4		
	1U5	1DN5	
S	1U5SF	1AS5	
BES	1U6		
T U	1V	6 Z 3	
G	1V2		
Ž	1V5	1AC5	
<u> </u>	1V6		
ш	1W4		
EC	1X2	1X2A, 1X2B	
~	1X2A	1 X2 B	
•	1X2B		
	1 Z 2		
	2A3	2A3H	
	2A3H	2A3	
	2A4G		
	2A5		
	2A6		
	2A7	2A7S	
	2A7S	2A7	
	2AF4	2AF4A, 2AF	4B
••	2AF4A	2AF4B	
12	⁺ Parallel-filam	ent circuits only.	§ May not work in all circuits.

Original fram

To Replace	Use
2AF4B 2B3	
2B5 2B7	2B7S
2B7S	2B7
2BN4 2BN4A 2CY5	2BN4A 2BN4 2EA5, 2EV5
2E5 2EA5	2CY5, 2EV5
2EN5 2ER5 2ES5 2EV5 2FH5	2ES5, 2FH5 2FH5 2EA5, 2CY5 2ES5
2FV6 2G5 2J2 2S/4S 2T4	
2V2 2V3G 2W3 2W3GT 2X2	2W3GT 2W3 2X2A, 879, 2X2/879
2X2A 2Z2/G84 3A2 3A3 3A8GT	2X2, 879, 2X2/879
3AF4A 3AJ8 3AL5 3AU6 3AV6	3BA6

^{*} Parallel-filament circuits only.

	To Replace	Use
	3B2	3A3
	3B7	
	3BA6	3AU6
	3BC5	3CE5
	3B E 6	3CS6
	3BN4	3BN4A
	3BN4A	3BN4
	3BN6	
	3BU8	3GS8
•	3B X 6	3BY7
œ	3BY6	
8	3BY7	3BX6
3B2-3GS8	3BZ6	3CB6, 3CF6, 3DK6
38	3C2	
• •	3C4	3E5
ES	3C5GT	3Q5, 3Q5G, 3Q5GT
∞	3C6	XXB
) -	3CB6	3BZ6, 3CF6, 3DK6
ნ	3CE5	3BC 5
Z	3CF6	3BZ6, 3CB6, 3DK6
>	3CS6	3BE6
_	3CY5	3EA5, 3EV5
EC	3D6	, - <u>-</u>
~	3DK6	3B Z 6, 3CB6, 3CF6
•	3DT6	
	3E5	3C4
	3E6	301
	3EA5	3CY5, 3EV5
	3EH7	3023,0273
	3EJ7	
	3ER5	3ES5, 3FH5
	3ES5	3FH5
	3EV5	3CY5, 3EA5
	3FH5	3ES5
	3GS8	3BU8
14	* Parallel-filan	nent circuits only. § May not work in all circuits.

To Replace	Use
3LE4 3LF4 3Q4	
3Q5G	3Q5GT, 3C5GT
3Q5GT	3Q5G, 3C5GT
3S4	
3S4SF 3V4	3W4, 3W4/3S4SF
3W4	3S4SF, 3W4/3S4SF
3W4/3S4SF	3W4, 3S4SF
3Z4	
4AU6	4BA6
4BA6	4AU6
4BC5	4CE5
4BC8	4BQ7A, 4BS8, 4BX8, 4BZ7, 4BZ8, 4CX7, 5BK7A
4BE6	4CS6
4BL8	
4BN4	
4BN6	
4BQ7A	4BC8, 4BS8, 4BX8, 4BZ7, 4BZ8, 4CX7, 5BK7A
4BS8	4BC8, 4BQ7A, 4BX8, 4BZ7, 4BZ8, 4CX7, 5BK7A
4BU8	4GS8
4BX8	4BC8, 4BQ7A, 4BS8, 4BZ7, 4BZ8, 4CX7, 5BK7A
4B Z 6	4CB6, 4DE6, 4DK6
4B Z 7	4BC8, 4BQ7A, 4BS8, 4BX8, 4BZ8, 4CX7, 5BK7A
4BZ8	4BC8, 4BQ7A, 4BS8, 4BX8, 4BZ7, 4CX7, 5BK7A
4CB6	4BZ6, 4DE6, 4DK6
4CE5	4BC5
4CM4	
* Danallal flament	ainquita only & May not work in all ainquita

	To Replace	Use
	4CS6	4BE6
	4CX7	4BC8, 4BQ7A, 4BS8, 4BX8, 4BZ7, 4BZ8, 5BK7A
	4CY5	
	4DE6	4BZ6, 4CB6, 4DK6
	4DK6	4BZ6, 4CB6, 4DE6
	4DT6	
	4EH7	
	4EJ7	
•	4ES8	
œ	4EW6	
583	4GS8	4BU8
4CS6-5BS8	5AM8	
S	5AN8	
4	5AQ5	
ES	5AR4	
∞	5AS4	5AS4A, 5DB4, 5U4GB
J L	5AS4A	5AS4, 5DB4, 5U4GB
	5AS8	
ڻ ح	5AT8	5CG8
E < .	5AU4	5V3
	5AV8	5B8§
REC	5AW4	5AS4, 5AS4A, 5AU4, 5DB4, 5R4GYB, 5U4GA, 5U4GB, 5V3
•	5AX4GT	5AR4, 5R4GY, 5R4GYA, 5R4GYB, 5T4
	5AZ4	5AR4, 5AX4GT, 5CG4, 5R4GY, 5R4GYA, 5R4GYB, 5T4, 5V4G, 5V4GA, 5Y3G, 5Y3GA, 5Y3GT, 5Z4, 5Z4G, 5Z4GT
	5B8	5AV8§
	5BE8	5BR8§, 5CL8§, 5CL8A§, 5FV8§
	5BK7A	4BC8, 4BQ7A, 4BS8, 4BX8, 4BZ7, 4BZ8, 4CX7
	5BQ7A	5BS8, 5BZ7
	5BR8	5BE8§, 5CL8§, 5CL8A§, 5FV8§
	5BS8	5BQ7A, 5BZ7
16	* Parallel-filar	ment circuits only. § May not work in all circuits.

To Replace	Use
5BT8 5BW8	
5BZ7 5CG4 5CG8	5BQ7A, 5BS8 5AR4, 5Z4, 5Z4G, 5Z4GT 5AT8
5CL8 5CL8A 5CM6 5CM8 5CQ8	5CL8A, 5BE8§, 5BR8§, 5FV8§ 5CL8, 5BE8§, 5BR8§, 5FV8§ 5CZ5 5EA8§, 5GH8§, 5U8§
5CR8 5CU4 5CZ5 5DB4 5DH8	5AS4, 5AS4A, 5U4GB
5EA8 5EH8 5EU8 5FV8 5GH8	5GH8, 5U8, 5CQ8§ 5BE8§, 5BR8§, 5CL8§, 5CL8A§ 5EA8, 5U8, 5CQ8§
5J6 5R4GY 5R4GYA 5R4GYB 5T4	5R4GYA, 5R4GYB 5R4GY, 5R4GYB
5T8 5U4G 5U4GA	5AR4, 5R4GYB 5U4GA, 5U4GB, 5AR4, 5AS4, 5AS4A, 5DB4, 5R4GYB, 5T4 5U4GB, 5AS4, 5AS4A, 5DB4, 5R4GYB
5U4GB	5AS4, 5AS4A, 5DB4
5U8 5V3 5V4G 5V4GA 5V6GT	5EA8, 5GH8, 5CQ8§ 5AU4 5V4GA, 5AR4 5V4G, 5AR4

^{*} Parallel-filament circuits only.

To Replace	Use
5W4	5W4G, 5W4GT, 5AR4, 5AZ4, 5CG4, 5R4GY, 5R4GYA, 5R4GYB, 5T4, 5V4G, 5V4GA, 5Y3G, 5Y3GA, 5Y3GT, 5Z4, 5Z4G, 5Z4GT
5W4G	5W4, 5W4GT, 5AR4, 5AZ4, 5CG4, 5R4GY, 5R4GYA, 5R4GYB, 5T4, 5V4G, 5V4GA, 5Y3G, 5Y3GA, 5Y3GT, 5Z4, 5Z4G, 5Z4GT
5W4GT	5W4, 5W4G, 5AR4, 5AZ4, 5CG4, 5R4GY, 5R4GYA, 5R4GYB, 5T4, 5V4G, 5V4GA, 5Y3G, 5Y3GA, 5Y3GT, 5Z4, 5Z4G, 5Z4GT
5X3 5X4G	13, 80 5X4GA
5X4GA 5X8	
5Y3G	5Y3GA, 5Y3GT, 5AR4, 5AX4GT, 5AZ4, 5CG4, 5R4GY, 5R4GYA, 5R4GYB, 5T4, 5V4, 5V4GA, 5 Z 4, 5Z4G, 5Z4GT
5Y3GA	5Y3G, 5Y3GT, 5AR4, 5AX4GT, 5AZ4, 5CG4, 5R4GY, 5Y4GYA, 5R4GYB, 5T4, 5V4, 5V4GA, 5Z4, 5Z4G, 5Z4GT
5Y3GT	5Y3G, 5Y3GA, 5AR4, 5AX4GT, 5AZ4, 5CG4, 5R4GY, 5R4GYA, 5R4GYB, 5T4, 5V4, 5V4GA, 5Z4, 5Z4G, 5Z4GT
5Y4G 5Y4GA 5Y4GT	5Y4GA, 5Y4GT 5Y4G, 5Y4GT 5Y4G, 5Y4GA
5 Z 3	83
5 Z 4	5Z4G, 5Z4GT, 5AR4, 5CG4, 5V4G, 5V4GA
5Z4G 5Z4GT 6A3	5Z4, 5Z4GT, 5AR4, 5CG4, 5V4G, 5V4GA 5Z4, 5Z4G, 5AR4, 5CG4, 5V4G, 5V4GA
	Clament simulta culture (C. Many materials in all simulta

18

* Parallel-filament circuits only. § May

§ May not work in all circuits.

To Replace	Use
6A4 6A5G 6A6	CAZO
6A7 6A7S	6A7S 6A7
6A8 6A8G 6A8GT 6AB4 6AB5	6A8G, 6A8GT 6A8, 6A8GT 6A8, 6A8G
6AB6G 6AB7 6AB8	6N6G*
6AC5G 6AC5GT	6AC5GT 6AC5G
6AC6GT 6AC7 6AD5G 6AD5GT 6AD6G	6AJ7 6AD5GT 6AD5G
6AD7G 6AD8 6AE5G 6AE5GT 6AE6G	6AE5GT, 6AF5G 6AE5G, 6AF5G
6AE7G 6AE7GT 6AE8 6AF3 6AF4	6AE7GT 6AE7G 6AF4A
6AF4A 6AF5G 6AF6G 6AF6GT 6AF7G	6AF4 6AE5G, 6AE5GT 6AF6GT 6AF6G

^{*} Parallel-filament circuits only.

To Replace	Use
6AQ6 6AQ7GT	6AT6*, 6AV6*, 6BK6*, 6BT6*
6AQ8	6DT8*
6AR5 6AR6	6AQ5*§, 6AQ5A*§
6AR7GT 6AR8	
6AS5 6AS6	
6AS7G	6AS7GA, 6080
6AS7GA 6AS8	6AS7G, 6080
6AT6	6AV6, 6BK6, 6BT6, 6AQ6*
6AT8	6AT8A, 6CG8, 6CG8A
6AT8A	6CG8A, 6AT8*, 6CG8*
6AU4GT	6AU4GTA, 6CQ4, 6DA4A, 6DE4
6AU4GTA	6CQ4
6AU5GT 6AU6	6AV5GA, 6AV5GT 6AU6A, 6BA6, 7543
6AU6A	6AU6*, 7543*, 6BA6*
6AU7	7AU7
6AU8	6AU8A, 6AW8, 6AW8A
6AU8A	6AU8, 6AW8, 6AW8A
6AV4 6AV5GA	6BX4* 6AV5GT, 6AU5GT
6AV5GT	6AV5GA, 6AU5GT
6AV6	6AT6, 6BK6, 6BT6, 6AQ6*
6AW7GT	
6AW8	6AW8A, 6AU8, 6AU8A, 6EB8*
6AW8A	6AW8, 6AU8, 6AU8A, 6EB8*
6AX4GT	6AX4GTA, 6AX4GTB, 6CQ4*, 6DA4, 6DA4A, 6DE4*
6AX4GTA	6AX4GTB, 6CQ4*, 6DA4, 6DA4A, 6DE4*
6AX4GTB	6DA4A*
6AX5GT	

^{*} Parallel-filament circuits only. § May not work in all circuits.

	To Replace	Use
	6AX6G 6AX7 6AX8 6AZ8 6B3	6U8, 6U8A, 6GH8, 6EA8, 6GJ8*, 6CQ8§
•	6B4G 6B5 6B6G 6B7 6B7S	6Q7, 6Q7G, 6Q7GT 6B7S 6B7
6AX6G-6BE8A	6B8 6B8G 6B8GT 6BA5 6BA6	6B8G, 6B8GT 6B8, 6B8GT 6B8, 6B8G 6AU6, 6AU6A
G TUBES	6BA7 6BA8 6BA8A 6BC4 6BC5	6BA8A, 6BH8 6BA8, 6BH8 6CE5, 6AG5, 6AK5*, 6CY5*§, 6EA5*§, 6EV5*§
RECEIVIN	6BC7 6BC8	6BQ7, 6BQ7A, 6BS8, 6BX8, 6BZ7, 6BZ8, 6CX7, 6CH7, X155, 6BK7*, 6BK7A*, 6BK7B*
•	6BD4 6BD4A 6BD5GT 6BD6 6BD7	6BD4A 6AV5GT, 6AV5GA, 6AU5GT
	6BE6 6BE7	6CS6
	6BE8	6BE8A, 6BR8§, 6BR8A§, 6CL8§, 6CL8A§, 6FV8§
	6BE8A	6BE8*, 6BR8*§, 6BR8A§, 6CL8§, 6CL8A§, 6FV8§
22	* Parallel-filam	ent circuits only. § May not work in all circuits.

Original fram

To Replace	Use
6BF5 6BF6 6BF7 6BF7A 6BG6G	6BU6 6BF7A, 6BG7 6BF7, 6BG7 6BG6GA
6BG6GA 6BG7 6BH5 6BH6 6BH8	6BG6G 6BF7, 6BF7A 6BA8, 6BA8A
6BJ5 6BJ6 6BJ6A 6BJ7 6BJ8	6BJ6A 6BJ6
6BK4 6BK5 6BK6 6BK7	6AT6, 6AV6, 6BT6, 6AQ6* 6BK7A, 6BK7B, 6BC8*, 6BQ7*, 6BQ7A*, 6BS8*, 6BX8*, 6BZ7*, 6BZ8*, 6CH7*, 6CX7*, X155
6BK7A 6BK7B	6BK7, 6BK7B, 6BC8*, 6BQ7*, 6BQ7A*, 6BS8, 6BX8*, 6BZ7*, 6BZ8*, 6CH7*, 6CX7*, X155* 6BK7*, 6BK7A, 6BC8*, 6BQ7*, 6BQ7A*, 6BS8*, 6BX8*, 6BZ7*, 6BZ8*, 6CH7*,
6BK8 6BL4 6BL7GT 6BL7GTA	6CX7*, X155* 6AU4GT, 6AU4GTA 6BL7GTA, 6DN7, 6BX7GT 6BL7GT, 6BX7GT, 6DN7
6BL8 6BM5 6BM8 6BN4	6BN4A

To Replace	Use
6BN4A 6BN5 6BN6 6BN7 6BN8	6BN4
6BQ5 6BQ6G	7189, 7189A 6BQ6GA, 6BQ6GTA, 6BQ6GTB, 6BQ6GTB/6CU6, 6CU6, 6DQ6, 6DQ6A, 6DQ6B, 6FH6
6BQ6GA	6BQ6G, 6BQ6GTA, 6BQ6GTB, 6BQ6GTB/6CU6, 6CU6, 6DQ6, 6DQ6A, 6DQ6B, 6FH6
6BQ6GT	6BQ6G, 6BQ6GA, 6BQ6GTA, 6BQ6GTB 6BQ6GTB/6CU6, 6CU6, 6DQ6, 6DQ6A, 6DQ6B, 6FH6
6BQ6GTA	6BQ6G, 6BQ6GA, 6BQ6GTB, 6BQ6GTB 6CU6, 6CU6, 6DQ6, 6DQ6A, 6DQ6B, 6FH6
6BQ6GTB	6BQ6GTB/6CU6, 6CU6, 6DQ6, 6DQ6A, 6DQ6B, 6FH6
6BQ6GTB/6CU6	6BQ6GTB, 6CU6, 6DQ6, 6DQ6A, 6DQ6 6FH6
6BQ7	6BQ7A, 6BC8, 6BS8, 6BX8, 6BZ7, 6BZ8 6CH7, 6CX7, X155, 6BK7*, 6BK7A*, 6BK7B*
6BQ7A	6BQ7, 6BC8, 6BS8, 6BX8, 6BZ7, 6BZ8, 6CH7, 6CX7, X155, 6BK7*, 6BK7A*, 6BK7B*
6BR5	
6BR7	
6BR8	6BR8A, 6BE8§, 6BE8A§, 6CL8§, 6CL8A§, 6FV8§
6BR8A	6BR8*, 6BE8*§, 6BE8A§, 6CL8§, 6CL8A§, 6FV8§
6BS5	· · · · · · · · · · · · · · · · · · ·
* Parallel-filament	circuits only. § May not work in all circui

24

To Replace	Use
6BS7	
6BS8	6BC8, 6BQ7, 6BQ7A, 6BX8, 6BZ7, 6BZ8, 6CH7, 6CX7, X155, 6BK7*, 6BK7A*, 6BK7B*
6BT4	
6BT6 6BT8 6BU4 6BU5	6AT6, 6AV6, 6BK6, 6AQ6*
6BU6	6BF6
6BU8 6BV7 6BV8 6BW4 6BW6	6GS8
6BW7 6BW8	
6BX4	6AV4*
6BX6	6BY7, 6EC7*
6BX7GT	6BL7GT, 6BL7GTA
6BX8	6BC8, 6BQ7, 6BQ7A, 6BS8, 6BZ7, 6BZ8, 6CH7, 6CX7, X155, 6BK7*, 6BK7A*, 6BK7B*
6BY4	CDVECA
6BY5G	6BY5GA
6BY5GA 6BY6	$6\mathrm{BY5G}$
6BY7	6BX6, 6EC7*
6BY8	, , , , , , , , , , , , , , , , , , , ,
6BZ6	6CB6, 6CB6A, 6CF6, 6DE6, 6DK6
6BZ7	6BC8, 6BQ7, 6BQ7A, 6BS8, 6BX8, 6BZ8, 6CH7, 6CX7, X155, 6BK7*, 6BK7A*, 6BK7B*
6BZ8	6BC8, 6BQ7, 6BQ7A, 6BS8, 6BX8, 6BZ7, 6CH7, 6CX7, X155, 6BK7*, 6BK7A*, 6BK7B*

^{*} Parallel-filament circuits only.

r.~

[§] May not work in all circuits.

Digitized by Google

To Replace	Use	
6CL5		
6CL6		
6CL8	6CL8A, 6BE8 6BE8*§, 6B	A§, 6BR8A§, 6FV8§, R8*§
6CL8A	6CL8, 6BE8A 6BE8*§, 6B	§, 6BR8A§, 6FV8§, R8*§
6CM4		
6CM5		
6CM6	6C Z 5	
6CM7		
6CM8		
6CN6		
6CN7		
6CQ4		
6CQ6		
6CQ8	6U8A§, 6EA8 6GJ8*§	§, 6GH8§, 6U8*§, 6AX8*§,
6CR4	Ü	
6CR5		
6CR6		
6CR8		
6CS5		
6CS6	6BE6	
6CS7		
6CS8		
6CT7		
6CU5		
6CU6	6BQ6GTB, 6B 6DQ6A, 6D	Q6GTB/6CU6, 6DQ6, Q6B, 6FH6
6CU7		
6CU8		
6CV7		
6CW5		
6CX7	6BC8, 6BQ7, 6	BBQ7A, 6BS8, 6BX8, 6BZ7,
	6BZ8, 6CH7 6BK7B*	7, X155, 6BK7*, 6BK7A*,
* Parallel-filament		§ May not work in all circuits.



	To Replace	Use
	6CX8	6AU8*, 6AU8A*, 6AW8*, 6AW8A*
	6CY5	6EA5, 6EV5, 6AG5*§, 6AK5*§, 6BC5*§, 6CE5*§
	6CY7	·
	6C Z 5	
	6D5G	
	6D6	78, 58AS*
	6D7	
•	6D8	6D8G
8	6D8G	6D8
ò	6DA4	6DA4A, 6CQ4, 6DE4
Q	6DA4A	6CQ4, 6DE4
8	6DA5	
9009-8X29	6DA6	6DG7*
	6DA7	
ES	6DB5	
∞	6DB6	
→	6DC6	6BZ6, 6CB6, 6CB6A, 6CF6, 6DE6, 6DK6
ড	6DC8	
Ž	6DE4	6AU4GT, 6AU4GTA, 6CQ4, 6DA4A
>	6DE6	6BZ6, 6CB6, 6CB6A, 6CF6, 6DC6, 6DK6
ш	6DE7	, , , , , , , , , , , , , , , , , , , ,
EC	6DG6GT	6W6GT, 6EF6, 6EY6, 6EZ5
~	6DG7	6DA6*
•	6DJ8	6ES8, 6FW8*
	6DK6	6BZ6, 6CB6, 6CB6A, 6CF6, 6DC6, 6DE6
	$6\mathrm{DL}5$	
	6DL7	
	6DN6	6EX6, 6CD6G, 6CD6GA
	6DN7	
	6DQ5	
	6DQ6	6DQ6A, 6DQ6B, 6FH6
	6DQ6A	6DQ6B, 6FH6
	6DQ6B	
28	* Parallel-filan	nent circuits only. § May not work in all circuits.



To Replace	Use
6DR6	6CJ6
6DR7	
6DR8	
6DS5	
6DS8	
6DT5	
6DT6	
6DT8	6AQ8*
6DW5	
6DX8	
6DY5	
6DY7	
6DZ7	
6DZ8	
6E5	
6E6	
6E7	
6E8G	
6EA5	6EV5, 6CY5, 6AG5*§, 6AK5*§, 6BC5*§, 6CE5*§
6EA7	6EM7
6EA8	6U8A, 6GH8, 6CQ8§, 6AX8*, 6GJ8*
6EB5	
6EB8	6GN8, 6AU8*, 6AU8A*
6EC7	6BX6*, 6BY7*
6EF6	6DG6GT, 6EY6, 6EZ5, 6W6GT
6EH5	
6EH7	
6EH8	
6EJ7	
6EM5	
6EM7	6EA7
6ER5	6ES5*, 6FH5*
6ES5	6FH5, 6ER5*
6ES6	6ET6
* Parallel-filament	circuits only. § May not work in all circuits.



	To Replace	Use
	6ES8	6DJ8, 6FW8*
	6ET6	6ES6
	6ET7	
	6EU7	
	6EU8	
	6EV5	6EA5, 6CY5, 6AG5*§, 6AK5*§, 6BC5*§, 6CE5*§
	6EV7	•
	6EW6	6GM6
•	6EW7	
ស	6EX6	
6ES8-6G5	6EY6	6EF6, 6EZ5
8 8	6EZ5	6EF6, 6EY6
6E	6EZ8	
	6F4	
ES	6F5	6F5G, 6F5GT
∞	6F5G	6F5, 6F5GT
⊢	6F5GT	6F5, 6F5G
<mark></mark>	6F6	6F6G, 6F6GT
Z	6F6G	6F6, 6F6GT
>	6F6GT	6F6, 6F6G
ш	6F7	6F7S
EC	6F7S	6F7
~	6F8G	
•	6FE5	
	6FG 6	
	6FH5	6ER5, 6ES5*
	6FH6	6DQ6B
	6FH8	
	6FM8	
	6FV6	
	6FV8	6BE8A§, 6BR8A§, 6CL8§, 6CL8A§, 6BE8*§, 6BR8*§
	6FW8	6DJ8*, 6ES8*
	6G5	6G5/6H5, 6H5, 6U5/6G5, 6U5
30	* Parallel-filan	nent circuits only. § May not work in all circuits.

To Replace	Use
6G5/6H5	6G5, 6H5, 6U5/6G5, 6U5
6G6G	
6GA8	6CG7*
6GC6	
6GE8	
6GH8	6EA8, 6U8A, 6CQ8§, 6AX8*, 6GJ8*, 6U8*
6GJ8	6AX8*, 6EA8*, 6GH8*, 6U8*, 6U8A*, 6CQ8*§
6GK6	
6GM6	6EW6
6GN6	
6GN8	6EB8, 6AU8*, 6AU8A*, 6AW8*, 6AW8A*
6GS8	6BU8
6H4	6H4GT
6H4GT	6H4
6H5	6G5, 6G5/6H5, 6U5, 6U5/6G5
6H6	6H6G, 6H6GT
6H6G	6H6, 6H6GT
6H6GT	6H6, 6H6G
6HC8	
6 J 4	
6J5	6J5G, 6J5GT, 6C5, 6C5G, 6C5GT
6 J 5G	6J5, 6J5GT, 6C5, 6C5G, 6C5GT
6J5GT	6J5, 6J5G, 6C5, 6C5G, 6C5GT
6 J 6	6J6A
6J6A	6J6*
6J7	6J7G, 6J7GT
6J7G	6J7, 6J7GT
6J7GT	6J7, 6J7G
6J8G	
6K5G	6K5GT
6K5GT	6K5G
6K6GT	
* Parallel-filament	circuits only. § May not work in all circuits.



To Replace	Use
6Q7G	6Q7, 6Q7GT, 6B6G
6Q7GT	6Q7, 6Q7G, 6B6G
6R3	
6R4	
6R6G	
6R7	6R7G, 6R7GT
6R7G	6R7, 6R7GT
6R7GT	6R7, 6R7G
6R8	
6S2	6S2A
6S2A	6S2
6S4	6S4A
6S4A	
6S7	6S7G
6S7G	6S7
6S8GT	
6SA7	6SA7G, 6SA7GT
6SA7G	6SA7, 6SA7GT
6SA7GT	6SA7, 6SA7G
6SB7Y	
6SC7	6SC7GT
6SC7GT	6SC7
6SD7GT	6SE7GT
6SE7GT	6SD7GT
6SF5	6SF5GT
6SF5GT	6SF5
6SF7	
6SG7	6SG7GT
6SG7GT	6SG7
6SH7	6SH7GT
6SH7GT	6SH7
6SJ7	6SJ7GT
6SJ7GT	6SJ7
6SK7	6SK7G, 6SK7GT, 6SS7* 6SS7GT*
6SK7G	6SK7, 6SK7GT, 6SS7*, 6SS7GT*
* Parallel-filament	circuits only. § May not work in all circuits.



	To Replace	Use
	6SK7GT 6SL7GT 6SN7GT 6SN7GTA 6SN7GTB	6SK7, 6SK7G, 6SS7*, 6SS7GT* 6SU7WGT 6SN7GTA, 6SN7GTB 6SN7GTB 6SN7GTA*
6SK7GT-6V5GT •	6SQ7 6SQ7G 6SQ7GT 6SR7 6SR7GT	6SQ7G, 6SQ7GT, 6SZ7* 6SQ7, 6SQ7GT, 6SZ7* 6SQ7, 6SQ7G, 6SZ7* 6SR7GT, 6ST7* 6SR7, 6ST7*
	6SS7 6SS7GT 6ST7 6SV7 6SZ7	6SS7GT, 6SK7*, 6SK7G*, 6SK7GT* 6SS7, 6SK7*, 6SK7G*, 6SK7GT* 6SR7*, 6SR7GT* 6SQ7*, 6SQ7G*, 6SQ7GT*
RECEIVING TUBES 6.	6T4 6T5 6T6 6T7G 6T8	6G5, 6G5/6H5, 6H5, 6U5/6G5, 6U5 6T8A, 6AK8
	6T8A 6U3 6U4GT 6U5	6T8*, 6AK8* 6AX4GT, 6AX4GTA, 6AX4GTB, 6CQ4, 6DA4, 6DA4A, 6W4GT 6G5, 6G5/6H5, 6H5, 6T5, 6U5/6G5
•	6U6GT 6U7G 6U8 6U8A	6Y6G, 6Y6GA, 6Y6GT 6K7, 6K7G, 6K7GT 6U8A, 6EA8, 6GH8, 6AX8, 6GJ8* 6U8*, 6EA8, 6GH8, 6AX8*, 6GJ8*, 6CQ8§
34	6V3 6V3A 6V4 6V5G 6V5GT * Parallel-filan	6V3A 6V3 6CA4 6V5GT 6V5G nent circuits only. § May not work in all circuits.
_ ,	- widing illust	Janes only. Janey not work in an elleutes.

To Replace	Use
6V6	6V6GT, 6V6GTA, 7408
6V6GT	6V6, 6V6GTA, 7408
6V6GTA	6V6*, 6V6GT*, 7408*
6V7G	
6V8	
6W4GT	6AX4GT, 6AX4GTA, 6AX4GTB, 6CQ4,
	6DA4, 6DA4A, 6U4GT
6W5G	
6W6GT	6DG6GT, 6EF6, 6EY6, 6EZ5
6W7G	
6X4	6BX4, 6AV4*
6X5	6X5G, 6X5GT
6X5G	6X5, 6X5GT
6X5GT	6X5, 6X5G
6X8	6X8A
6X8A	6X8*
6Y3G	
6Y5	6Y5V
6Y5V	6Y5
6Y6G	6Y6GA, 6Y6GT, 6U6GT
6Y6GA	6Y6G, 6Y6GT, 6U6GT
6Y6GT	6Y6G, 6Y6GA, 6U6GT
6Y7G	
6 Z 3	1V
6 Z 4	84, 84/6 Z 4
6 Z 5	12Z5, 6Z5/12Z5
6Z5/12Z5	6Z5, 12Z5
6 Z 7 G	
6ZY5G	
7A4	XXL
7A5	
7A6	
7A7	7B 7*
7A8	
7AB7	



* Parallel-filament circuits only.

CORNELL UNIVERSITY

§ May not work in all circuits.

Original from CORNELL UNIVERSITY

•
RECEIVING
G TUBES
7 57 –9BR8
•

To Replace	Use
7S7 7T7 7V7 7W7 7X6	
7X7 7Y4 7Z4 8AU8 8AU8A	XXFM 8AU8A, 8AW8A 8AU8, 8AW8A
8AW8A 8B8 8BA8A 8BH8 8BN8	8AU8, 8AU8A 8BH8 8BA8A
8BQ5 8BQ7A 8CG7 8CM7 8CN7	
8CS7 8CW5 8CX8 8CY7 8EB8	8GN8
8EM5 8ET7 8GN8 8SN7GTB 9A8	8EB8
9AK8 9AQ8 9AU7 9BR7 9BR8 * Parallel-filament	9CL8§ circuits only. § May not work in all circuits.



	To Replace	Use
	9BW6	
	9CL8	
	9DZ8	
	9EF6	
	9EN7	
	9GB8	
	9U8	9U8A
	9U8A	
_	9X8	
•	10	210T
70	10C8	
9BW6-12AD7	10DA7	
\ddot{I}	10 DE7	
Š	10DR7	
90	10EB8	
	10EG7	
S	10EW7	
TUBES	11	
⊃ ⊢	11C5	
	11CY7	
Ž	12	
>	12A4	
E	12A5	
O	12A6	12A6GT
K E	12A6GT	12A6
•	12A7	
	12A8	12A8G, 12A8GT
	12A8G	12A8, 12A8GT
	12A8GT	12A8, 12A8G
	12AB5	
	12AC5	
	12AC6	
	12AD5	
	12AD6	
	12AD7	12AX7*, 12AX7A*, 12DF7*, 12DM7*,
20	* Danallal £1	12DT7*, 7025*, 7025A*
38	raranei-man	nent circuits only. § May not work in all circuits.

To Replace	Use
12AE6 12AE6A 12AE7 12AF3	12AE6A, 12FT6 12AE6, 12FT6
12AF6 12AG6 12AH6 12AH7GT 12AH8	12BL6
12AJ6 12AJ7 12AL5 12AL8 12AQ5	
12AS5 12AT6 12AT7 12AU6 12AU7	12AV6, 12BK6, 12BT6 12AZ7*, 12AZ7A* 12BA6 12AU7A
12AU7A 12AV5GA 12AV6 12AV7 12AW6	12AU7 12AT6, 12BK6, 12BT6
12AX4GT 12AX4GTA 12AX4GTB 12AX7	12AX4GTA, 12AX4GTB, 12D4, 12D4A 12AX4GTB, 12D4, 12D4A 12AX7A, 12DF7, 12DT7, 7025,, 7025A, 12DM7*, 12AD7*
12AX7A 12AY7	12AX7, 12DF7, 12DT7, 7025, 7025A, 12AD7*, 12DM7*
12AI7 12AZ7 12AZ7A * Parallel-filament	12AZ7A, 12AT7* 12AZ7*, 12AT7* circuits only. § May not work in all circuits.



To Replace

Use

To Replace	Use
12BX6 12BY7 12BY7A 12BZ6 12BZ7	12BY7A, 12BV7, 12DQ7 12BY7*, 12DQ7, 12BV7*
12C5 12C5/12CU5 12C8 12CA5 12CM6	12C5/12CU5, 12CU5, 12R5 12C5, 12CU5, 12R5
12CN5 12CR5 12CR6 12CS5 12CS6	12BE6
12CT8 12CU5 12CU6	12C5, 12C5/12CU5, 12R5 12BQ6GTB, 12BQ6GTB/12CU6, 12DQ6, 12DQ6A, 12DQ6B
12CX6 12CY6	
12D4 12D4A 12DB5 12DE8	12D4A, 12AX4GTB
12DF5 12DF7	12AX7, 12AX7A, 12DT7, 7025, 7025A, 12AD7*, 12DM7*
12DK5 12DK7	, ,
12DL8 12DM5 12DM7	12AD7*, 12AX7*, 12AX7A*, 12DF7*, 12DT7*, 7025*, 7025A*
12DQ6 * Parallel-filament	12DQ6A, 12DQ6B c circuits only. § May not work in all circuits.



	To Replace	Use
	12DQ6A 12DQ6B	12DQ6B
	12DQ7	12BY7A, 12BY7*, 12BV7*
	12DS7	12DS7A
	12DS7A	12DS7
	12DT5	
	12DT6	
•	12DT7	12AX7, 12AX7A, 12DF7, 7025, 7025A, 12AD7*, 12DM7*
ñ	12DT8	,
12DQ6A-12FB5	12DU7	
7	12DV7	
∀	12DV8	
8	12DW5	
12	12DW7	7247
	12DW8	
ES	12DY8	
B	12DZ6	12EA6
-	12DZ8	
U	12E5GT	
Z	12EA6	12DZ6
E <	12EC8	
<u> </u>	12ED5	
EC	12EF6	
~	12EG6	
•	12EH5	
	12EK6	
	12EL6	
	12EM6	
	12EN6	12L6GT, 12W6GT
	12EZ6	
	12F5GT	
	12F8	
	12FA6	
42	12FB5 * Parallel-filan	nent circuits only. § May not work in all circuits.
74	i ai ailei-iliali	ions circuits only. 3 hay not work in an circuits.

Original from CORNELL UNIVERSITY

To Replace	Use
12FK6 12FM6 12FQ8 12FR8	
12FT6	12AE6, 12AE6A
12FX8 12G4 12G8 12GA6 12GC6	
12GN6 12H4 12H6 12J5	12J5GT
12J5GT	12J5
12J7 12J7G 12J7GT 12J8 12K5	12J7G, 12J7GT 12J7, 12J7GT 12J7, 12J7G
12K7G 12K7GT 12K8 12K8GT 12L6GT	12K7GT 12K7G 12K8GT 12K8 12W6GT, 12EN6
12L8GT 12Q7 12Q7G 12Q7GT 12R5	12Q7G, 12Q7GT 12Q7, 12Q7GT 12Q7, 12Q7G
12S7 12S8 12S8GT 12SA7 12SA7GT	12S8GT 12S8 12SA7GT, 12SY7 12SA7, 12SY7
* Parallel-filament	circuits only. § May not work in all circuits.



To Replace	Use
12SC7	
12SF5	12SF5GT
12SF5GT	12SF5
12SF7	
12SG7	
12SH7	12SH7GT
12SH7GT	12SH7
12SJ7	12SJ7GT
12SJ7GT	12SJ7
12SK7	12SK7GT
12SK7GT	12SK7
12SL7GT	
12SN7GT	12SN7GTA, 12SX7GT
12SN7GTA	
12SQ7	12SQ7GT
12SQ7GT	12SQ7
12SR7	12SR7GT, 12SW7
12SR7GT	12SR7, 12SW7
12SW7	12SR7, 12SR7GT
12SX7GT	12SN7GT, 12SN7GTA
12SY7	12SA7, 12SA7GT
12U7	
12V6GT	
12W6GT	12EN6, 12L6GT
12X4	
12 Z 3	14 Z 3
12 Z 5	6Z5, 6Z5/12Z5
13	5X3, 8 0
13CM5	
13DE7	
13DR7	
13EC7	
13EM7	
13GC8	
14A4	
* Parallel-fila	ment circuits only. § May not work in all circu

Original from CORNELL UNIVERSITY


Use
14A7/12B7, 12B7, 14H7 XXD
12B7, 14A7/12B7, 14A7
12Z3
16B, 81 circuits only. § May not work in all circuits.



TUBE SUBSTITUTION handbook

by

The Howard W. Sams Engineering Staff





To Replace	Use	
19BG6GA	19BG6G	
19C8 19CL8A	19 T 8	
19CS4		
19D8		
19DE7		
19EA8		
19J6 19T8	19C8	
1918 19V8	1908	
19X3		
19X8		
19Y3	19X3	
20		
21A6	21B6	
21B6	21A6	
21EX6 22		
22DE4		
24A	24S	
24S	24A	
25	25S, 1B5, 1B5/	
25A6	25A6G, 25A6G	
25A6G 25A6GT	25A6, 25A6GT 25A6, 25A6G	
	20A0, 20A0G	
25A7GT 25AC5G	25AC5GT	
25AC5GT	25AC5G	
25AV5GA	25AV5GT	
25AV5GT	25AV5GA	
25AX4GT	25D4	
25B5		
25B6G 25B8	25B8GT	
25B8GT	25B8G1 25B8	
* Parallel-filament		§ May not work in all circuits.



* Parallel-filament circuits only. § May not work in all circuits.

To Replace

25BK5 25BQ6GA Use

25BQ6GTB, 25BQ6GTB/25CU6, 25CU6,

To Replace	Use
25W4GT 25W6GT 25X6GT 25Y4GT 25Y5	25U4GT, 25AX4GT, 25D4 25C6G, 26C6GA, 25L6, 25L6GT 25Z5
25Z4 25Z5 25Z6 25Z6G 25Z6GT	25Y5 25Z6G, 25Z6GT 25Z6, 25Z6GT 25Z6, 25Z6G
26 26A6 26A7 26A7GT 26BK6	26A7GT 26A7
26C6 26CG6 26D6 26E6G 26Z5	
27 27S 28D7 28Z5 30	27S, 56, 56S 27, 56, 56S
30A5 31 31A3 32 32A8	1B4P, 1B4T, 951
32ET5 32L7GT 33 34 35 * Parallel-filament	35/51, 35S, 35S/51S, 51, 51S circuits only. § May not work in all circuits.



	To Replace	Use
	35/51	35, 51, 35S/51S, 35S, 51S
	35A3	
	35A5	
	35B5	
	35C3	
	35C5	
	35CD 6 GA	
•	35D5	
H	35DZ8	
.56	35EH5	
452	35GL6	
2/1	35HB8	
70	35L6GT	
4	35S	35S/51S, $51S$, $35/51$, 35 , 51
35/51-40Z5/45Z5GT	35S/51S	35S, 51S, 35/51, 35, 51
35	35W4	
	35Y4	
ES	35Z 3	
∞	35Z4GT	
⊢	35Z5G	35Z5GT
U	35Z5GT	35 Z 5G
Z	35Z6G	
E I <	36	36A, 64*, 64A*
	36A	36, 64*, 64A*
EC	36AM3	
~	37	76, 56AS*
•	38	
	38A3	
	39	39/44, 44
	39/44	39, 44
	40	
	40A1	
	40B2	AARK AKAKAM AKAKAM
	40Z5	40Z5/45Z5GT, 45Z5GT
	40Z5/45Z5GT	40Z5, 45Z5GT
50	- Parallel-niame	nt circuits only. § May not work in all circuits.

To Replace	Use
41 42 43	
44 45	39, 39/44 45A
45A 45A5 45B5 45Z3 45Z5GT	45 4075 4075 (4575CT)
46 47 48 49 50	40Z5, 40Z5/45Z5GT
50A1 50A5 50AX6G 50B5 50BK5	
50BM8 50C5 50C6G 50C6GA 50CA5	50C6GA 50C6G
50CD6G 50DC4 50EH5 50FE5 50FY8	
50L6GT 50X6 50Y6G 50Y6GT 50Y7GT	50Y6GT 50Y6G 50Z7G, 50Z7GT
* Parallel-filament	circuits only. § May not work in all circuits.



To Replace	Use
50Z6G	
50 Z 7G	50Z7GT, 50Y7GT
50Z7GT	50Z7G, 50Y7GT
51	51S, 35, 35/51, 35S/51S, 35S
51S	51, 35, 35/51, 35S/51S, 35S
52	
53	
55	55S
55N3	
55 S	55
56	56S, 27, 27S
56AS	76*
56S	56, 27, 27S
57	57S
57AS	6C6*,77*
57S	57
58	58S
58AS	6D6*, 78*
58S	58
59	
60E3	
64	64A, 36*, 36A*
64A	64, 36*, 36A*
65	65A
65A	65
67	67A, 37*, 37A*
67A	67, 37*, 37A*
68	68A
68A	68
70A7GT	
70L7GT	
75	75S
75S	75
76	37, 37A, 56AS*
77	6C6, 57AS*
78	6D6, 58AS
* Parallel-fila	ment circuits only. § May not work in all circuits.

To Replace	Use
79	
80	5X3, 13
81	16, 16B
82	82V, 88
82V	82, 88
83	83V, 5Z3
83V	83, 5Z3
84/6 Z 4 85	6Z4
85AS	
88	82, 82V
89	89Y
89Y	89
96	
117L7GT	117L7/M7GT, 117M7GT
117L7/M7GT	117L7GT, 117M7GT
117M7GT	117L7GT, 117L7/M7GT
117N7GT	
117P7GT	
117 Z 3	
117 Z4 GT	
117Z6G	117Z6GT
117Z6GT	117Z6G
182B/482B	71A
210T	10
401	
404A 417A	
417A 484	
807	
950	
951	1B4P, 1B4T, 32
954	, ,
955	
956	
957	
* Parallel-filament	circuits only. § May not work in all circuits.



To Replace	Use	
958A		•
959		
5642		
5879		
5881	6L6GC	
6080	6AS7G, 6AS7GA	
6267		
6550		
6973		
7025	7025A, 12AX7, 12AX7A, 12DF7, 12DT7, 12AD7*, 12DM7*	
7025A	7025, 12AX7, 12AX7A, 12DF7, 12DT7, 12AD7*, 12DM7*	
7027	7027A	
7027A		
7189	7189A	
7189A		
7199		
7247	12DW7	
7355		
7382		
7408	6V6, 6V6GT, 6V6GTA	
7543	6AU6, 6AU6A	
7581	6L6GC	
7591		
7695		
9001		
9002		
9003		
XXB	3C6	
XXD	14AF7	
XXFM	7X7	
XXL	7A4	
X155	6BC8, 6BQ7, 6BQ7A, 6BS8, 6BX8, 6BZ7, 6BZ8, 6CH7, 6CX7, 6BK7*, 6BK7A*, 6BK7B*	
* Parallel-filar	ment circuits only. § May not work in all circuits.	

Section 2 INDUSTRIAL SUBSTITUTES FOR RECEIVING TUBES

In this section are those American receiving tubes that can be replaced by industrial types. The receiving tubes are listed in the left-hand column and their industrial substitutes in the right-hand column. Each tube listed has one or more substitutes. If a tube type does not appear in the listing, an industrial substitute is not recommended.

This substitution list should be used in one direction only—that is, an industrial type to replace a standard type. If the equipment is already designed for an industrial tube, a standard receiving tube will not usually work as efficiently or as long as the original.

Substitutes marked with an asterisk (*) should be used only when the filament of the original tubes is wired in a parallel circuit.

Engineering

FIRST EDITION

FIRST PRINTING — JUNE, 1960 SECOND PRINTING — JUNE, 1960

TUBE SUBSTITUTION HANDBOOK

Copyright © 1960 by Howard W. Sams & Co., Inc., Indianapolis 6, Indiana. Printed in the United States of America.

Reproduction or use, without express permission, of editorial or pictorial content, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein.

Library of Congress Catalog Card Number: 60-13842



Use

To Replace

To Replace	Use
6BR7	6059
6BW6	6061
6C4	6C4W, 6C4WA, 6100, 6135
6C6	1221, 1223
6CB6	7732
6CH6	6132
6CL6	6677
6CQ6	6065
6F6	1611, 1621
6H6	6H6WGT
6J4	6J4WA
6 J 5	6J5WGT
6 J 6	6J6W, 6J6WA, 6099, 6101
6J7	1620
6L6	6L6WA, 6L6WGB, 1222, 1222A, 1614, 5881, 5932, 7581
6L7	1612
6Q7	6118
6SA7	5961
6SC7	6SC7GTY
6SJ7	6SJ7WGT, 5693
6SK7	6137
6SL7	6SL7WGT, 5691*, 6113
6SN7GT	6SN7WGT, 6SN7WGTA, 5692
6SU7	6SU7GTY, 6SU7WGT, 6188
6U8	6678, 7731
6V6	6V6GTY, 5871, 5992*, 7408
6X4	6X4W, 6X4WA, 5993*, 6063, 6202
6X5	6X5WGT
7A6	5679
7F8	7F8W
12AT7	12AT7WA, 6060, 6021, 6679, 7728
12AU7	12AU7WA, 5814*, 5814A*, 5814WA, 6067, 6189, 6680, 7730
12AX7	5751*, 5751WA*, 6057, 6681, 7025, 7025A, 7729



* Parallel-filament circuits only.

To Replace	Use	
12AY7	6072	
12J5	12J5WGT	
14C7	1280	
25Z6	25Z6WGT	
26E6G	26E6WG	
26 Z 5	26Z5W	
28D7	28D7W, 1238	
30	1230	
32	1229	
404A	5847	
417A	5842	
955	5731	

^{*} Parallel-filament circuits only.

Section 3

EUROPEAN SUBSTITUTES FOR AMERICAN TYPES

This section lists American receiving tubes and their European substitutes. American tubes are in the left-hand column, with their European equivalents in the right-hand column. Only those American types which can be replaced with European brands have been listed. For a list of European types with American equivalents, refer to Section 4.

Substitutes marked with an asterisk (*) should be used only when the filament of the original tube is wired in a parallel circuit.

	To Replace	
	1C1	1R5
	1C2	1AC6
	1D13	1A3
	1F2	1L4
	1F3	1T4
	1FD1	1AH5
	1FD9	1S5
	1P1	3C4
•	1P10	3S4
F	1P11	3V4
1C1-64SPT	3G10	7E 5
9	6D2	6AL5, 5726, 6058, 6097, 6663
2	6F10	6AC7, 6134
	6F12	6AM6
Z	6L12	6AQ8
<	6L34	6AQ4
R C	6LD3	6CV7
M K	6M2	6CD7
	6P9	6BM5
¥ - Z	6S5G	6E5
Z	6 Z 31	6X4, 5993*, 6063
EA	7D9	6AM5, 6516
0	7D10	6CH6, 6132
~	8D3	6AM6
EU	8D5	6BR7, 6059
•	8D7	6BS7
	9D6	6CQ6, 6065
	17N8	17C8
	19U3	19X3
	20D3	12AH8
	30C1	9A8
	30L1	7AN7
	62DDT	6CV7
	63TP	6AB8
	64SPT	6BX6
68	* Parallel-filame	nt circuits only.

To Replace

Use

To Replace	Use
65ME	6BR5
66KU	6BT4
67PT	6CK5
108C1/OB2	OB2, 6074, 6627
141TH	14K7
150B2/6354	6354
150C2/OA2	OA2
150C3/OD3	OD3
171DDP	17C8
403B	5591, 6AK5*, 5654*, 6096*
451PT	45A5
A1834	6AS7G, 6080
A2521	6CR4
AX9003	5894
B36	12SX7GT
B65	6SN7WGT, 5692, 6180
B152	12AT7, 6060, 6201, 6679
B309	12AT7, 6060, 6201, 6679
B329/12AU7	12AU7, 5814, 6067, 6189, 6680
B339/12AX7	12AX7, 5751, 6057, 6681, 7025
B719/ECC85	6AQ8
BF61	6CK5
BF451	45A5
BPM04	6AQ5
D2M9	6AL5, 5726, 6058, 6097, 6663
D63	6H6
D77	6AL5, 5726, 6058, 6097, 6663
D152	6AL5, 5726, 6058, 6097, 6663
DA90/1A3	1A3
DAC32	1H5GT
DAF91/1S5	1S5
DAF92	1U5
DAF96/1AH5	1AH5
DCC90/3A5	3A5
DD7	6AM5, 6516
* Parallel-filament	circuits only.



To Replace	Use
E80T/6218	6218
E81L/6686	6686
E83F/6689	6689
E88CC	6922, 6DJ8*
E90CC/5920	5920
E91H/6687	6687
E180CC	7062
E180F/6688	6688
E182CC/7119	7119
E188CC/7308	7308
EA52	6923
EAA91	6AL5, 5726, 6058, 6097, 6663
EABC80	6AK8
EAF42	6CT7
EB34	6H6
EB91	6AL5, 5726, 6058, 6097, 6663
EBC41	6CV7
EBC81	6BD7
EBC90/6AT6	6AT6, 6066
EBC91/6AV6	6AV6, 6066
EBF32	6B8
EBF80/6N8	6N8
EBF83	6DR8
EBF89/6DC8	6DC8
EC80/6Q4	6Q4
EC81/6R4	6R4
EC86	6CM4
EC90/6C4	6C4, 6100, 6135
EC91/6AQ4	6AQ4
EC92/6AB4	6AB4
ECC35 ECC81/12AT7 ECC82/12AU7 ECC83/12AX7 ECC85/6AQ8 * Parallel-filament	6SL7*, 5691*, 6113* 12AT7, 6060, 6201, 6679 12AU7, 5814, 6067, 6189, 6680 12AX7, 5751, 6057, 6681, 7025 6AQ8 circuits only.



To Replace	Use
EL41	6CK5
EL71	5902
EL81	6CJ6
EL83	6CK6
EL84/6BQ5	6BQ5, 7320
EL85	6BN5
EL86/6CW5	6CW5
EL90/6AQ5	6AQ5, 6005, 6095
EL91	6AM5, 6516
EL360	6CM5
EL620	5672
EL821	6CH6, 6132
EM34/6CD7	6CD7
EM80/6BR5	6BR5 /
EM81/6DA5	6DA5
EM84/6FG6	6FG6
EM840	6FG6
EQ80	6BE7
EY70	5641
EY80	6U3
EY81	6R3
EY82	6N3
EY84	6374
EY88/6AL3	6AL3
EZ35/6X5G	6X5G
EZ40	6BT4
EZ80/6V4	6V4
EZ81/6CA4	6CA4
EZ90/6X4	6X4, 5993*, 6063
EZ91	6AV4
GZ30/5Z4	5Z4
H63	6F5GT
HABC80	19T8
HBC90/12AT6	12AT6
HBC91/12AV6	12AV6
* Parallel-filamen	t circuits only.



	HCH81	12AJ7
	HD14	1H5GT
	HF93/12BA6	12BA6
	HF94	12AU6
	HK90/12BE6	12BE6
	HL90	19AQ5
	HL92/50C5	50C5
	HL94	30A5
	HM04	6BE6, 5750
142	HY90/35W4	35W4
HCH81-N142	KT32	25L6, 6046
81	KT66	6L6GC, 7581
IJ	LZ319	9A8
Ĭ	M8079	6AL5, 5726, 6058, 6097, 6663
	M8080	6C4WA, 6100, 6135
Z	M8081	6J6WA, 6099, 6101
CA	M8082	6AM5, 6516
	M8083	6AM6
Щ Ж	M8091	6374
- A M E	M8100	6AK5W, 5591*, 5654, 6096
∀	W18100	0AK5W, 5551 ', 5054, 0050
Z	M8136	12AU7WA, 5814, 6067, 6189, 6680
E A	M8137	12AX7, 5751, 6057, 6681, 7025
•	M8161	6CQ6,6065
8 0	M8162	12AT7WA, 6060, 6201, 6679
EU	M8163	6354
_	M8195	6267
•	M8196	6AS6W, 5725, 6187
	M8212	6AL5W, 5726, 6058, 6097, 6663
	N14	1C5GT
	N17	3S4
	N18	3Q4
	N19	3V4
	N77	6AL5, 5726, 6058, 6097, 6663
	N78	6BJ5
	N142	45A5
74	* Parallel-filame	nt circuits only.

To Replace

Use

Digitized by Google

To Replace	Use	
N144	6AM5, 6516	
N147	6M6G	
N150	6CK5	
N152	21A6	
N153	15A6	
N154	16A5	
N309/PL83	15A6	
N329	16A5	
N709	6BQ5, 7320	
N727/6AQ5	6AQ5, 6005, 6095	
OSW2190	6AC7, 6134	
OSW2600	6AC7, 6134	
OSW3109	6H6	
OSW3110	6E5	
PABC80	9AK8	
PC86	4CM4	
PCC84	7AN7	
PCC85/9AQ8	9AQ8	
PCC88	7DJ8	
PCF80	9A8	
PCF82	9U8	
PCL82/16A8	16A8	
PCL84	15DQ8	
PL36	25E5	
PL81	21A6	
PL82	16A5	
PL83	15A6	
PL84	15CW5	
PM04	6BA6, 5749, 6660	
PM05	6AK5, 5591*, 5654, 6096	
PM07	6AM6	
PP6BG	6M6G	
PY31	25Z4	
PY80	19X3	
PY82	19Y3	
* Parallel-filament circuits only.		



	To Replace	Use
	QA2406 R16/1T2	12AT7, 6060, 6201, 6679 1T2
	R17 R18 R52	6157 6374 5Z4
QA2406-X17 •	RGN1503 SN1039A SP6 TS52/ECC91 U37/1T2 U78 U147	7E5 5591 6AM6 6J6, 6099, 6101 1T2 6X4, 5993*, 6063 6X5G
N QA24	U147 U149 U152 U154	7Y4 19X3 19Y3
N-AMERICAN	U709 UBF80 UCH42 UCH81 UCL82/50BM8	6CA4 17C8 14K7 19D8 50BM8
UROPEA	UF41 UL41 UL84/45B5 UU9 UY85	12AC5 45A5 45B5 6BT4 38A3
•	V2M70 V61 VP6 W17 W77	6X4, 5993*, 6063 6BT4 6CQ6, 6065 1T4 6CQ6, 6065
	W719/EF85 W727/6BA6 WD142 X14 X17	6BY7 6BA6, 5749, 6660 12S7 1A7GT 1R5
76	* Parallel-filament circuits only.	

To Replace	Use
X63	6A8
X148	787
X727/6BE6	6BE6, 5750
XCC189	4ES8
X719	6AJ8
Z14	1N5GT
Z 63	6J7
Z77	6AM6
Z152	6BX6
Z300T/0A4G	0A4G
Z719	6BX6
Z729	6267
ZA2	954
ZD17	185
ZD152	6N8

^{*} Parallel-filament circuits only.

Section 5 PICTURE TUBE SUBSTITUTES

This section lists all picture tubes, from the 10- to the 30-inch sizes. This listing is numerical-alphabetical, with the substitutes shown in the right-hand column. Substitutes are not recommended for some types and, for this reason, are not shown in many instances. The listing of a certain tube type as a substitute for another one does not necessarily mean the reverse is true. Always refer to the left-hand column for the original type number. Then find the substitute in the right-hand column.

Minor changes may be necessary when a picture tube is substituted. These changes are indicated by various symbols following the type number. The key to these symbols is given below. Be absolutely certain to refer to this key.

Key to Footnotes:

- *Omit ion trap.
- ** Add ion trap.
 - 1 Parallel-filament circuits only.
 - ² Mechanical changes may be required.
 - ³ A change of accelerator-grid voltage may be required.
 - ⁴ A change of focusing voltage may be required.
 - 5 A change of brightness-control voltage may be required.
 - 6 Add high-voltage filter capacitor.
 - 7 Ground the Aquadag coating.
 - 8 Change the anode connector.
 - 9 Change the ion trap.

12TP46

To Replace

10ABP4

Use

10ABP4A, 10ABP4B, 10ABP4C

To Replace	Use
12QP4	12QP4A, 12ZP4 ⁸ , 12ZP4A ⁸ , 12KP4 ^{8*} , 12KP4A ^{8*}
12QP4A	12QP4, 12ZP4 ⁸ , 12ZP4A ⁸ , 12KP4 ^{8*} , 12KP4A ^{8*}
12RP4	12JP4*
12TP4 12UP4 12UP4A	12LP47, 12LP4A7, 12LP4C7 12UP4A, 12UP4B9 12UP4, 12UP4B9
12UP4B 12VP4	12UP4°, 12UP4A° 12VP4A
12VP4A 12WP4 12XP4 12YP4	12VP4 12VP4
12ZP4	12ZP4A, 12KP4*, 12KP4A*
12ZP4A 14ACP4	12ZP4, 12KP4*, 12KP4A*
14AEP4 14AJP4	14ARP4 ^{3,5}
14ARP4 14ASP4	14AEP4 ^{3,5}
14ATP4 14AUP4 14AWP4 14AZP4 14BAP4	14AW4P 14AUP4
14BP4	14BP4A, 14CP4, 14CP4A, 14EP4
14BP4A	14BP4, 14CP4, 14CP4A, 14EP4
14CP4	14CP4A, 14BP4, 14BP4A, 14EP4
14CP4A 14DP4	14CP4, 14BP4, 14BP4A, 14EP4
14EP4 14FP4 14GP4 14HP4	14BP4, 14BP4A, 14CP4, 14CP4A
14KP4	14KP4A



To Replace	Use
16GP4A 16GP4B 16GP4C 16HP4 16HP4A	16GP4, 16GP4B, 16GP4C 16GP4, 16GP4A, 16GP4C 16GP4, 16GP4A, 16GP4B 16HP4A 16HP4
16JP4 16JP4A 16KP4 16KP4A 16LP4	16JP4A 16JP4 16KP4A, 16RP4, 16RP4A 16KP4, 16RP4, 16RP4A 16LP4A, 16ZP4
16LP4A 16MP4 16MP4A 16QP4	16LP4, 16ZP4 16MP4A 16MP4
16RP4 16RP4A 16SP4 16SP4A	16RP4A, 16KP4, 16KP4A 16RP4, 16KP4, 16KP4A 16SP4A, 16WP4 ^{3,5} , 16WP4A ^{3,5} , 16WP4B ^{3,5} 16SP4, 16WP4 ^{3,5} , 16WP4A ^{3,5} ,
16TP4 16UP4 16VP4 16YP4 16WP4	16WP4B ^{3, 5} 16UP4 ^{5, 6} 16TP4 ^{5, 7} 16WP4A ⁷ , 16WP4B ⁷ , 16SP4 ^{3, 5} ,
16WP4A 16WP4B 16XP4 16ZP4	16SP4A ^{3.5} 16WP4B, 16WP4 ⁶ , 16SP4 ^{3.5} , 16SP4A ^{3.5} 16WP4A, 16WP4 ⁶ , 16SP4 ^{3.5} , 16SP4A ^{3.5} 16LP4, 16LP4A
17AP4 17ASP4 17ATP4 17ATP4A 17AVP4 17AVP4A	17ATP4A, 17AVP4, 17AVP4A 17ATP4, 17AVP4, 17AVP4A 17AVP4A, 17ATP4, 17ATP4A 17AVP4, 17ATP4, 17ATP4A



To Replace	Use
17DAP4 17DBP4 17DCP4 17DEP4 17DHP4	
17DJP4 17DKP4 17DLP4 17DQP4 17DRP4	17DCP4*
17DSP4 17DTP4 17DWP4 17DXP4 17EAP4	
17FP4 17FP4A 17GP4 17HP4 17HP4A	17FP4A 17FP4 17HP4A, 17HP4B, 17RP4, 17RP4C 17HP4, 17HP4B, 17RP4, 17RP4C
17HP4B 17JP4 17KP4 17KP4A 17LP4	17HP4, 17HP4A, 17RP4, 17RP4C 17BP4, 17BP4A, 17BP4B, 17BP4C 17KP4A 17KP4 17LP4A, 17VP4, 17VP4B
17LP4A 17QP4 17QP4A 17RP4 17RP4C	17LP4, 17VP4, 17VP4B 17QP4A, 17UP4, 17YP4 17QP4, 17UP4, 17YP4 17RP4C, 17HP4, 17HP4A, 17HP4B 17RP4, 17HP4, 17HP4A, 17HP4B
17SP4 17TP4 17UP4 17VP4 17VP4B	17QP4, 17QP4A, 17YP4 17VP4B, 17LP4, 17LP4A 17VP4, 17LP4, 17LP4A

To Replace	Use
20DP4B	20DP4, 20CP4, 20CP4B, 20CP4C, 20DP4A ⁷ , 20DP4C ⁷ , 20CP4A ⁷ , 20CP4D ⁷
20DP4C	20DP4A, 20CP4A, 20CP4D, 20DP46, 20DP4B6, 20CP46, 20CP4B6, 20CP4C6
20FP4	
20GP4	
20HP4	20HP4B, 20HP4C, 20HP4A ⁷ , 20HP4D ⁷ , 20LP4 ⁷ , 20MP4 ⁷
20HP4A	20HP4D, 20LP4, 20MP4, 20HP46, 20HP4B6, 20HP4C6
20HP4B	20HP4, 20HP4C, 20HP4A ⁷ , 20HP4D ⁷ , 20LP4 ⁷ , 20MP4 ⁷
20HP4 C	20HP4, 20HP4B, 20HP4A ⁷ , 20HP4D ⁷ , 20LP4 ⁷ , 20MP4 ⁷
20HP4D	20HP4A, 20LP4, 20MP4, 20HP46, 20HP4B6, 20HP4C6
20JP4	
20LP4	20MP4, 20HP4A, 20HP4D, 20HP46, 20HP4B6, 20HP4C6
20MP4	20LP4, 20HP4A, 20HP4D, 20HP46, 20HP4B6, 20HP4C6
21ACP4	21ACP4A, 21AMP4, 21AMP4A, 21BSP4, 21AQP46, 21AQP4A6
21ACP4A	21ACP4, 21AMP4, 21AMP4A, 21BSP4, 21AQP46, 21AQP4A6
21AFP4	• , •
21ALP4	21ALP4A, 21ALP4B, 21ATP4, 21ATP4A, 21ATP4B, 21BTP4, 21BAP4*, 21BNP4*
21ALP4A	21ALP4, 21ALP4B, 21ATP4, 21ATP4A, 21ATP4B, 21BTP4, 21BAP4*, 21BNP4*
21ALP4B	21ALP4, 21ALP4A, 21ATP4, 21ATP4A, 21ATP4B, 21BTP4, 21BAP4*, 21BNP4*

To Replace	Use
21AWP4 21AXP22 21AXP22A	
21AYP4	21XP4, 21XP4A
21BAP4 21BCP4	21BNP4, 21CVP4 21BDP4, 21AUP4**, 21AUP4A**, 21AUP4B**, 21AVP4**, 21AVP4A**, 21AVP4B**
21BDP4	21BCP4, 21AUP4**, 21AUP4A**, 21AUP4B**, 21AVP4**, 21AVP4A**, 21AVP4B**
21BNP4	21BAP4, 21CVP4
21BSP4	21ACP4, 21ACP4A, 21AMP4, 21AMP4A, 21AQP46, 21AQP4A6
21BTP4	21ALP4, 21ALP4A, 21ALP4B, 21ATP4, 21ATP4A, 21ATP4B, 21BAP4*, 21BNP4*
21CBP4	21CBP4A, 21CHP4 ^{3,5} , 21CXP4 ^{3,5} , 21DSP4 ^{3,5}
21CBP4A	21CBP4, 21CHP4 ^{3,5} , 21CXP4 ^{3,5} , 21DSP4 ^{3,5}
21CDP4	21CDP4A, 21CKP4*
21CDP4A	21CDP4, 21CKP4*
21CEP4	21CEP4A
21CEP4A	21CEP4
21CGP4	
21CHP4	21CXP4 ³ , 21DSP4 ³ , 21CBP4 ^{3,5} , 21CBP4A ^{3,5}
21CKP4	
21CLP4	
21CMP4	
21CQP4	21CSP4 ¹
21CSP4	21CQP4 ¹
21CUP4	

Use

To Replace

To Replace	Use
21EXP4 21EYP4 21FAP4 21FP4 21FP4A	21FP4A ⁷ , 21FP4C ⁷ 21FP4 ⁶ , 21FP4C
21FP4C 21JP4 21JP4A 21KP4 21KP4A	21FP46, 21FP4A 21JP4A 21JP4 21KP4A ⁷ 21KP4 ⁶
21MP4 21WP4 21WP4A 21XP4 21XP4A	21WP4A 21WP4 21XP4A, 21AYP4 21XP4, 21AYP4
21YP4 21YP4A 21ZP4 21ZP4A 21ZP4B	21YP4A 21YP4 21ZP4A ⁷ , 21ZP4B ⁷ 21ZP4B, 21ZP4 ⁶ 21ZP4A, 21ZP4 ⁶
22AP4A 22AP4A 23BP4 23CP4 23DP4	22AP4A 22AP4
23EP4 23FP4 23GP4 23HP4 23JP4	
23KP4A 23KP4A 23RP4 23SP4 23TP4	23KP4A

	To Replace	Use
	23UP4	
	23VP4	
	24ADP4	24CP4, 24CP4A, 24QP4, 24TP4, 24VP4, 24VP4A
	24AEP4	
	24AHP4	24ALP4, 24BAP4 ³
	24AJP4	24ATP4
	24ALP4	24AHP4, 24BAP4³
	24AMP4	
•	24ANP4	24DP4, 24DP4A, 24YP4, 24AEP4*, 24ZP4*
4TP.	24AP4	24AP4A, 24AP4B
7	24AP4A	24AP4, 24AP4B
P4	24AP4B	24AP4, 24AP4A
23UP4-24TP4	24AI 4B 24AQP4	21111 1, 21111 111
_	24ASP4	
ES	24ATP4	24AJP4
8	24AUP4	
⊃	24AVP4	
8	24AXP4	
>	24BAP4	24AHP4³, 24ALP4³
CT	24BP4	
<u> </u>	24CP4	24CP4A, 24ADP4, 24QP4, 24TP4, 24VP4, 24VP4A
•	24CP4A	24CP4, 24ADP4, 24QP4, 24TP4, 24VP4, 24VP4A
	24DP4	24DP4A, 24ANP4, 24YP4, 24AEP4*, 24ZP4*
	24DP4A	24DP4, 24ANP4, 24YP4, 24AEP4*, 24ZP4*
	24QP4	24ADP4, 24CP4, 24CP4A, 24TP4, 24VP4, 24VP4A
	24TP4	24ADP4, 24CP4, 24CP4A, 24QP4, 24VP4, 24VP4A

To Replace	Use
24VP4	24VP4A, 24ADP4, 24CP4, 24CP4A, 24QP4, 24TP4
24VP4A	24VP4, 24ADP4, 24CP4, 24CP4A, 24QP4, 24TP4
24XP4	24ADP4, 24CP4, 24CP4A, 24QP4, 24TP4, 24VP4, 24VP4A
24YP4	24ANP4, 24DP4, 24DP4A, 24AEP4*, 24ZP4*
24ZP4	24AEP4, 24ANP4**, 24DP4**, 24DP4A**, 24YP4**
27AP4	
27EP4	27GP4, 27NP4 ⁷ , 27RP4 ⁷
27GP4	27EP4, 27NP4 ⁷ , 27RP4 ⁷
27LP4	
27MP4	
27NP4	27RP4, 27EP46, 27GP46
27RP4	27NP4, 27EP46, 27GP46
27SP4	27UP4
27UP4	27SP4
27VP4	
27WP4 30BP4	

-NOTES-

SECTION 1 — RECEIVING TUBES


-- NOTES --SECTION 2 -- RECEIVING-INDUSTRIAL

SECTION 3 — AMERICAN-EUROPEAN

-NOTES-

SECTION 4 — EUROPEAN-AMERICAN

SECTION 5 — PICTURE TUBES



Howard W. Sams Tube Substitution Handbook fills the need often experienced by service technicians confronted with the necessity for making suitable tube replacements. The book lists over 1,500 American receiving tubes, including over 300 which can be replaced by European types. Also listed are 400 picture tubes, 179 European tubes that can be replaced by American types, and 78 receiving tubes that can be replaced by industrial types. Compiled by the engineering staff of Howard W. Sams & Co., Inc., this book is an invaluable reference for the service technician.



zed by Ra

HOWARD W. SAMS & CO., INC.
THE BOBBS-MERRILL COMPANY, INC.

Original from